





## Heavy Duty 8-Lug Spare Tire Carrier Instructions Part #86060

## **Mounting Instructions**

- 1. Using the spare tire carrier and spare tire as a guide, determine a suitable mounting location on trailer frame.
- 2. Slide Grade 5 hex head bolt and washer (not included) through front (top) tire carrier, over the frame and through the rear mounting bracket. Use the bolt pattern that fits closest to the frame. Loosely mount with Grade 5 nyloc nut (not provided), repeat for bottom bolt/washer/nut.
- 3. Using the spare tire to determine the correct holes to use, place the carriage bolts provided for mounting the spare tire in the holes of the tire mounting plate. Bolt heads should be on the back side of the tire carrier. Secure bolts with "star" washers.
- 4. Check position of the tire mount for proper clearance with the spare tire before tightening bolts.
- 5. Once position is determined tighten both mounting bolts/nuts.
- 6. Mount spare tire and tighten lug nuts.

## **Must Purchase Separately:**

Mounting Hardware Option One

- 2 5/8" Grade 5 Hex Head Bolts {length determined by frame width}
- 2 5/8" Grade 5 Nyloc Nuts
- 4 5/8" Washers

## Mounting Hardware Option Two

2 -5/8" Grade 5 Hex Head Bolts {length determined by frame width}

*342110*,A1113

- 2 5/8" Grade 5 Nuts
- 2 5/8" Lock Washers
- 2 5/8" Washers

